



**IMPORTANT NOTE!**  
 WRAP CENTER SECTION WITH 2" MIN. WIDTH TAPE & EPOXY

1/4" DOWEL 2" LONG L.E. HOLD DOWN - INSTALL AFTER WRAPPING JOINT

**C.G. NOTE**  
 BALANCE POINT SHOWN IS THE DRY C.G. FOR ADVANCED FLIER. 1/4" FWD FOR 1st FLIGHT

© RCM ALL COMMERCIAL RIGHTS RESERVED

# NEW ERA III REVISITED

A DESIGN UPDATE BY JOE BESHAR

DESIGNED BY	DON DEWEY	INKED BY	DICK KIDD
DRAWN BY	LEE RENAUD		

SCALE: 0 1 2 3 4 5 6

PLANNING 1219